

# NEC SV9100 Handset Time Change Guide



**Keep handy for changes between BST and GMT**

## Changing the time on your SV9100

- Using a display key telephone
- Ensure that you do not have a call in progress
- Press SPK key (bottom right hand side of phone)
- Dial 828
- Key in time in 24 hour format (e.g. 1545 = 3.45 pm)
- Press SPK key to hang up and complete

If you experience any difficulties resetting the time please contact DSM on:

**T: 0116 2426999**

**[E: service@dalys.co.uk](mailto:service@dalys.co.uk)**

**[www.dalys.co.uk](http://www.dalys.co.uk)**



Maintaining Business Communications